

What's included

Parts List Page 1




(A) 1 x Top Lock




(B) 1 x Bottom Lock



(C) 1 x Top Hinge



(D) 1 x Bottom Hinge




(E1) 1 x Fast Mount™ Locking Rail with one screw hole **(E2)** 1 x Fast Mount™ Hinge Rail with two screw holes




(F1) 1 x Spirit Level
(F2) 1 x Marker Tool


Marker Tool comes inserted within the Spirit Level



(G) 4 x Wall Plugs




(H1) 2 x Small Lower Spacer
(H2) 1 x Large Lower Spacer




(I) 4 x Small Screws
3 x 50mm and 1 x shorter screw




(J) 4 x Medium Screws
3 x 70mm and 1 x shorter screw




(K) 4 x Large Screws
3 x 80mm and 1 x shorter screw




(L) 2 x Extra Long Screws
1 x 100mm and 1 x shorter screw



(M) 2 x Inner Spacers




(N1) 2 x Small Outer Spacer Covers
(N2) 1 x Large Outer Spacer Cover



6 x Spacer Inserts
(O) 2 x thin **(P)** 2 x medium
(Q) 2 x thick

What's included

Parts List Continued




(R) 1 x Screw Fit Clear-View Gate



(S) 2 x Allen Key



(T) 1 x Removal Tool



(U1) 1 x Left and 1 x Right One-Way Stopper **(U2)** 1 x Long Barrel Nut

Step by step installation guide



The Top and Bottom Locks are marked A and B on the back. Slide A into the end marked A, and B into the end marked B on the Fast Mount™ Locking Rail (E1) until they both snap into place. End A is the top of your Rail.



The Top and Bottom Hinges are marked C and D on the back. Slide C into the end marked C, and D into the end marked D on the Fast Mount™ Hinge Rail (E2) until they both snap into place. End C is the top of your Rail.